

Evaluation of pre-treatment methods for improving the enzymatic hydrolysis of lignocellulosic waste

Dragana Mladenović¹, Aleksandra Djukić-Vuković¹, Saša Lazović², Jelena Pejin³, Sunčica Kocić-Tanackov³, Ljiljana Mojović¹


¹Faculty of Technology and Metallurgy, University of Belgrade, Serbia

²Institute of Physics Belgrade, University of Belgrade, Serbia


³Faculty of Technology, University of Novi Sad, Serbia



- **Lignocellulosic biomass** represents the most abundant renewable raw material that could be converted into high-value bioproducts





- Not fully exploited due to the low yields of bioproducts obtained
- Low yields are often attributed to incomplete hydrolysis of cellulose molecules which are protected inside the complex structure of lignocellulose (by lignin and hemicellulose)
- Other factors hinder hydrolysis of cellulose – crystallinity, porosity and extent of polymerization
- A wide range of pre-treatment strategies have been investigated, and they can be broadly categorized into physical, chemical, and biological methods



- The goal of pre-treatment is to break down the lignin protective barrier, remove hemicellulose, release cellulose and facilitate the subsequent enzymatic hydrolysis to fermentable sugars.


Pre-treatment of lignocellulosic biomass using high-temperature methods

Comparison of microwave and conventional heating – temperature distribution



Conventional heat source

- Contact heating
- Slow heating
- Longer reaction time
- Superficial heating (occurs at the surface)
- Lower level of control
- Higher energy consumption



Microwave

- Non-contact heating
- Rapid heating
- Shorter reaction time
- Volumetric heating (uniform heat distribution)
- Higher level of control
- Lower energy consumption

Materials and methods

Corn husk

Grounding and sieving

PRE-TREATMENT METHODS

Conventional heating

Hydrothermal
Deionized water
60 min at 121 °C

Dilute sulfuric acid (2%)
30 min., 60 min.
121 °C

Sodium-hydroxide (10%)
30 min., 60 min.
121 °C

Microwave heating

Microwave assisted alkali treatment
sodium-hydroxide (10%)
Power of 300 W, 2 min., 4 min.

Pre-treated biomass was thoroughly washed with water


Enzymatic hydrolysis by cellulase complex Cellic® CTec2,
50 °C for 24 h

The saccharification efficiency of each pre-treatment was
assessed by determining the concentration of reducing
sugars.


Results



COB



HUSK



■ Ash ■ Cellulose ■ Hemicellulose ■ Lignin

Fig. 1. Biochemical composition of corn cob and husk.

Results

Enzymatic hydrolysis of pre-treated corn husk




Fig. 2. Hydrothermal pre-treatment.




Fig. 3. Dilute acid pre-treatment.

Results

Enzymatic hydrolysis of pre-treated corn husk




Fig. 4. Alkali pre-treatment.




Fig. 5. Microwave assisted alkali pre-treatment.

Results




Table 1. Glucose yield after enzymatic hydrolysis of pre-treated corn husk.

Pre-treatment type	Glucose yield (%)
Hydrothermal	33.79 ± 2.78
Dilute acid	51.51 ± 1.07
Alkali	53.79 ± 0.95
Microwave	68.37 ± 1.12
Control	13.56 ± 1.17

Fig. 6. Reducing sugar concentration after enzymatic hydrolysis of pre-treated corn husk.



Conclusions

- Microwave assisted alkali treatment was found to be highly efficient in increasing the reducing sugar yield.
- A 4-fold increase in reducing sugar yield was obtained after enzymatic hydrolysis of pre-treated corn husk as compared to untreated sample.
- In this way pre-treated corn husk could be used as carbohydrate source for the production of lactic acid or other valuable products.



Thank you for your attention!



University of Belgrade, Faculty of Technology and Metallurgy

e-mail: dmladenovic@tmf.bg.ac.rs

ACKNOWLEDGMENTS

This work was funded by the Ministry of Education, Science and Technological development, Republic of Serbia, project number TR 31017 and Project #I-1 of Scientific and Technological Collaboration of Republic of Serbia and PR China.