

J. Almeida¹, R. Craveiro², E.P. Mateus¹, S. Barreiros², A. Paiva², A.B. Ribeiro¹

¹CENSE, Department of Sciences and Environmental Engineering

²LAQV@Requimte, Department of Chemistry

TUNGSTEN RECOVERY AND ARSENIC REMOVAL FROM SECONDARY RESOURCES DEEP EUTETIC SOLVENTS IN THE ELECTRODIALYTIC PROCESS














How to remove harmful compounds & recover critical raw materials from secondary resources?







MATRIX CHARACTERIZATION



Castro-Gomes, Mud collection at Panasqueira Mine, 2018

Sample

Rejected fraction from sludge circuit
(tube output; pumped directly to the
Panasqueira dam)

→ Low conductivity

$$0.8 \pm 0.4 \text{ mS/cm}$$

→ Acidic pH

$$5.3 \pm 0.5$$

→ Arsenic content

$$\text{As: } 1675 \pm 564 \text{ mg/kg}$$

→ Tungsten content

$$\text{W: } 130 \pm 31 \text{ mg/kg}$$

→ Other elements of interest

$$\text{Cu: } 731 \pm 270 \text{ mg/kg}$$


$$\text{Sn: } 38 \pm 9 \text{ mg/kg}$$

MATRIX ELEMENTS

X-Ray Fluorescence (XRF)
Semi-Quantitative Data (%)



XRF spectrometer



DEEP EUTETIC SOLVENTS

Acids, amides, amines and alcohols as liquid $\leq 100\text{ }^{\circ}\text{C}$

Deep Eutetic Solvents = Quaternary ammonium or metal salt + Hydrogen bond donor (HDB)

	Ionic Liquids	Deep Eutetic Solvents (natural products)
Low price	X	✓
Low toxicity	X	✓
100% atom economy	X	✓
Biodegradable	X	✓
Low vapor pressure	✓	✓
Low volatility	✓	✓

DEEP EUTETIC SOLVENTS

Acids, amides, amines and alcohols as liquid $\leq 100\text{ }^{\circ}\text{C}$


Deep Eutetic Solvents = Quaternary ammonium or metal salt + Hydrogen bond donor (HDB)

Why DES?



	Ionic Liquids	Deep Eutetic Solvents (natural products)
Low price	X	✓
Low toxicity	X	✓
100% atom economy	X	✓
Biodegradable	X	✓
Low vapor pressure	✓	✓
Low volatility	✓	✓


ELECTRO-BASED TREATMENT


→ **Electrokinetic (EK)** and **Electrodialytic (ED)** treatments consist in a low current density (mA/cm^2) application between a pair of electrodes to promote removal/separation of substances, with an ionic exchange membrane interposed in the ED treatment



(A) 3 compartments ED cell
(B) & (C) 2 compartments ED cell
AEM - Anionic exchange membrane
CEM - Cationic Exchange membrane








Mining residues (MR)



Arsenic

Tungsten




Mining residues (MR)



Arsenic


Tungsten

- 1 Selection of the most efficient DES for As and W extraction from the matrix



1 Selection of the most efficient DES for As and W extraction from the matrix


2 Potential of the EK process combined with DES to improve As and W extraction from the matrix



- 1 Selection of the most efficient DES for As and W extraction from the matrix
- 2 Potential of the EK process combined with DES to improve As and W extraction from the matrix
- 3 Feasibility of the ED process to separate As and W in a compartment apart from the matrix

1 Selection of the most efficient DES for As and W extraction from the matrix

- DES tested
- **ChCl:MA** - Choline Chloride:Malonic Acid (1:2)
 - **ChCl:OA** - Choline Chloride:Oxalic Acid (1:1)
 - **ChCl:LA** - Choline Chloride:Lactic Acid (1:2)
 - **PA:U** - Propionic Acid:Urea (2:1)



Liquid/solid = 9

Stirring

10 days

DES + MR


METHODOLOGY

2 Potential of the EK process combined with DES to improve As and W extraction from the matrix

DES tested with higher As and W extraction

- ChCl:MA - Choline Chloride:Malonic Acid (1:2) ↑As
- ChCl:OA - Choline Chloride:Oxalic Acid (1:1) ↑W

50 & 100 mA
Liquid/Solid=9
Stirring
4 days



DES + MR +H₂O
(1.5% ChCl:MA & 1.5% ChCl:OA)

METHODOLOGY

3 Feasibility of the ED process to separate As and W in a compartment apart from the matrix

DES tested with higher As and W extraction

- ChCl:MA - Choline Chloride:Malonic Acid (1:2) ↑As
- ChCl:OA - Choline Chloride:Oxalic Acid (1:1) ↑W


50 & 100 mA

Liquid/Solid=9


Electrolyte 0.01 M NaNO₃

Stirring

4 days




DES + MR + H₂O
(1.5% ChCl:MA & 1.5% ChCl:OA)




1 Selection of the most efficient DES for As and W extraction from the matrix

Arsenic and Tungsten extraction




1 Selection of the most efficient DES for As and W extraction from the matrix

Arsenic and Tungsten extraction




2 Potential of the EK process combined with DES to improve As and W extraction from the matrix

Extraction percentages in relation to DES experiments without current




2 Potential of the EK process combined with DES to improve As and W extraction from the matrix



Extraction percentages in relation to DES experiments without current



VOLTAGE, pH & CONDUCTIVITY CONTROL




- 50 mA - ChCl:OA
- 50 mA - ChCl:MA
- 100 mA - ChCl:OA
- 100 mA - ChCl:MA




RESULTS & DISCUSSION

3 Feasibility of the ED process to separate As and W in a compartment apart from the matrix




RESULTS & DISCUSSION

3 Feasibility of the ED process to separate As and W in a compartment apart from the matrix



RESULTS & DISCUSSION


3 Feasibility of the ED process to separate As and W in a compartment apart from the matrix




ELECTROLYTE BEHAVIOR

Mass and Percentage of elements reaching the electrolyte along the experiments


Arsenic content




Arsenic accumulated percentage in the electrolyte



Tungsten content



Tungsten accumulated percentage in the electrolyte




- 50 mA - ChCl:MA
- 50 mA - ChCl:OA
- 100 mA - ChCl:MA
- 100 mA - ChCl:OA

- 50 mA - ChCl:MA
- 50 mA - ChCl:OA
- 100 mA - ChCl:MA
- 100 mA - ChCl:OA


ELECTROLYTE BEHAVIOR

Percentage of elements from the total As and W extracted that reached the electrolyte




ELECTROLYTE BEHAVIOR

Percentage of elements from the total As and W extracted that reached the electrolyte



1 Selection of the most efficient DES for As and W extraction from the matrix

- Different DES demonstrated higher extraction efficiencies for different elements
- ChCl:MA (1:2) extracted a maximum of 12% for As
- ChCl:OA (1:1) extracted a maximum of 9% for W



CONCLUSIONS


2 Potential of the EK process combined with DES to improve As and W extraction from the matrix

→ Deep Eutetic solvents and EK treatment synergy potentiated the extraction

- As extraction increased 21% (100 mA, ChCl:OA)

- W extraction increased 10% (100 mA, ChCl:MA)

Compared to DES experiments with no current




CONCLUSIONS

3 Feasibility of the ED process to separate As and W in a compartment apart from the matrix

→ ED treatment enable to separate As and W, improving the migration of the elements from the matrix to the electrolyte compartment

- From the total As extracted, 82% (100 mA, ChCl:MA) migrated to the electrolyte
- From the total W extracted, 75% (50 mA, ChCl:OA) migrated to the electrolyte





Thank you!

js.almeida@campus.fct.unl.pt

ACKNOWLEDGMENTS

- This PhD work is part of the EcoCoRe Doctoral Program. The author acknowledges the PhD fellowship awarded by the Portuguese Foundation for Science and Technology (PD\BD\135170\2017)
- This work has received funding from the European Union's Horizon 2020 research and innovation programme under the Marie Skłodowska-Curie grant agreement No.778045 (e.THROUGH - H2020-MSCA-RISE-2017-778045)
- J. Almeida acknowledges her PhD supervisor team: Professor Paulina Faria, Professor Alexandra Ribeiro and Doctor António Santos Silva

