


 UNIVERSITY OF YAMANASHI

Ultrafine Bubble Diffuser for Enhancing Hydrogenotrophic Denitrification of Groundwater Treatment

 **Rawintra Eamrat**^a, Yuya Tsutsumi^a, Tatsuru Kamei^b,
 Willawan Khanichaidecha^c, and Futaba Kazama^b

^a Interdisciplinary Graduate School of Medicine and Engineering, University of Yamanashi, Yamanashi, Japan
^b Interdisciplinary Research Centre for River Basin Environment, University of Yamanashi, Yamanashi, Japan
^c Department of Civil Engineering, Faculty of Engineering, Naresuan University, Phitsanulok, Thailand


13th IWA specialized conference on small water and wastewater systems (Greece-Athens, 2016)


 UNIVERSITY OF YAMANASHI

Introduction

Hydrogenotrophic Denitrification-(Biological treatment)

Biological reduction of **nitrate** to **nitrogen gas** under **anaerobic conditions** by direct immobilization of autohydrogenotrophic bacteria.



Key of this research focusing on H₂ supply
 How to??
 Increase H₂ effectiveness under simple system
 Save H₂ supply (lowest H₂ with high efficiency)


 (Nepal)

Introduction

Dissolve
in water


H₂ → **Gas bubble** → **Bubbling generator**



Bubble distribution
 Surface area
 Solubility
 Energy consumption

Ultrafine bubble diffuser ("MiBoS")

(Tsukasa ITO, Environmental Engineering Lab at University of Gunmu, Japan)










Arbitrary Function Generator Pressure controller MiBoS³





Objective

-  To comparative the physical characteristic and biological activity between **ultrafine bubble system** and **common bubble system** with suspended growth reactor
-  To determine the **specific hydrogen gas consumption** and the **effectiveness of hydrogen gas supply** from both systems
-  To investigated the **microbial community** present in the system.



4





9/23/2016

	Diffuser Type	Media for microorganisms attachment	Influent NO _x -N (mg/L)	HRT (h)	H ₂ supply (g/d)	Removal efficiency (%)	H ₂ effectiveness (mgN/mg H ₂)	Reference
g factor	Bubble stone	No	1000	480	2.14	100	116.82	Mousavi, Ibrahim, & Aroua (2013)
g factor	Commercial bubble stone	No	20	3	1.34	100	12.38	Ghafari et al. (2009)
g factor	Air stone	Yes	20	2.5	9.00	96	58.88	Khanitchaidecha et al. (2012)
d factor	Fixed nozzles	Yes	340	1.0	11.57	82	347.20	Vasilidou et al. (2009)
d factor	Aquarium diffusing stone	Yes	20	2.0	12.86	80	41.38	Lee et al. (2010)
d factor	Pressurized gas tank	Yes	150	16.0	0.64	100	316.41	Park et al. (2005)
d factor	Air stone	No	40	12.0	0.13	16	196.92	This study
d factor	Ultrafine bubble	No	40	12.0	0.13	98	1206.15	This study

☐ **Total bacterial community**

Next Generation Sequencing method (illumina MiSeq)





Fig8. Relative abundance of microbial community in the phylum and class levels under air stone and ultrafine bubble systems

Total bacterial community



- ❖ *Hydrogenophaga* sp., *Thauera* sp. and unclassified genus in *Rhodocyclaceae* might be responsible for HD process and the excellent performance on nitrogen removal.
- ❖ *Thauera* sp. was the predominant genus at ultrafine bubble
- ❖ *Methyloversatilis* sp. was the predominant genus at normal

Ultrafine bubble supply system has efficiency and H₂ utilization higher than normal bubble supply system in both physical part and biological part

- High solubility (dissolve hydrogen concentration) and long retention time
- High volumetric mass transfer (0.045 s^{-1}) $\gg$ 20 times
- High system performance (99% of N removal) with less H_2 supply (1 mL/min)
- High H_2 effectiveness (1206.15 mgN/gH_2) under simple design, which was comparative with other research
- Save H_2 (low H_2 supply but high system performance)

The use of an **ultrafine bubble** diffuser is an option for enhancing the performance of a hydrogenotrophic denitrification reactor

9/23/2016

Acknowledgements



This research was performed with partial financial assistance from the "Project for Hydro-Microbiological Approach for Water Security in Kathmandu Valley, Nepal" under the Science and Technology Research Partnership for Sustainable Development (SATREPS) program of JST and JICA, and the Japan Society for the Promotion of Science KAKENHI GRANT number 26340059.



17

Thank you for your kind attention



18

Next-Generation Sequencing method (illumina MiSeq)

